





# 57R Series Flange Installation Instructions


2225 W Pershing Rd. Chicago, IL 60609 - 773.847.1400 - [www.newstarlighting.com](http://www.newstarlighting.com)

## IMPORTANT SAFE GUARDS:


- THIS PRODUCT MUST BE INSTALLED IN ACCORDANCE WITH THE APPLICABLE INSTALLATION CODE BY A PERSON FAMILIAR WITH THE CONSTRUCTION AND OPERATION OF THE PRODUCT AND THE HAZARDS INVOLVED.
- DISCONNECT POWER BEFORE BEGINNING INSTALLATION.
- FIXTURE MUST BE INSTALLED IN COMPLIANCE WITH THE NATIONAL ELECTRIC CODE AND ANY LOCAL CODES.
- TO BE INSTALLED ONLY BY A QUALIFIED ELECTRICIAN.
- PROPER GROUNDING IS REQUIRED TO INSURE PERSONAL SAFETY.
- READ ALL FIXTURE MARKINGS AND LABELS TO ENSURE CORRECT INSTALLATION OF FIXTURE.
- RISK OF FIRE, USE A MINIMUM OF 90C SUPPLY CONNECTORS.




57R24



57R14



57R22



57R12




# 57R Series Flange Installation Instructions


2225 W Pershing Rd. Chicago, IL 60609 - 773.847.1400 - [www.newstarlighting.com](http://www.newstarlighting.com)

## INSTALLATION INSTRUCTIONS:

1. Remove door frame fasteners.



2. Remove (4) fasteners to uninstall LED gear tray .








# 57R Series Flange Installation Instructions


2225 W Pershing Rd. Chicago, IL 60609 - 773.847.1400 - [www.newstarlighting.com](http://www.newstarlighting.com)

3. Raise fixture in to ceiling.


4. Adjust swing arms accordingly.



DETAIL A



Rotate screw clockwise or counter clockwise  
to adjust swing arm as needed.




DETAIL B



# 57R Series Flange Installation Instructions

2225 W Pershing Rd. Chicago, IL 60609 - 773.847.1400 - [www.newstarlighting.com](http://www.newstarlighting.com)

5. Make necessary electrical connections then re-attach LED gear tray with fasteners.



6. Fasten frame screws to secure frame and complete install.

