



SSR Series-Grid Installation Instructions


2225 W Pershing Rd. Chicago, IL 60609 - 773.847.1400 - www.newstarlighting.com

IMPORTANT SAFE GUARDS:

- THIS PRODUCT MUST BE INSTALLED IN ACCORDANCE WITH THE APPLICABLE INSTALLATION CODE BY A PERSON FAMILIAR WITH THE CONSTRUCTION AND OPERATION OF THE PRODUCT AND THE HAZARDS INVOLVED.
- DISCONNECT POWER BEFORE BEGINNING INSTALLATION.
- FIXTURE MUST BE INSTALLED IN COMPLIANCE WITH THE NATIONAL ELECTRIC CODE AND ANY LOCAL CODES.
- TO BE INSTALLED ONLY BY A QUALIFIED ELECTRICIAN.
- PROPER GROUNDING IS REQUIRED TO INSURE PERSONAL SAFETY.
- READ ALL FIXTURE MARKINGS AND LABELS TO ENSURE CORRECT INSTALLATION OF FIXTURE.
- RISK OF FIRE, USE A MINIMUM OF 90C SUPPLY CONNECTORS.



INSTALLATION INSTRUCTIONS:

1. Remove door frame fasteners.



GRID COMPATIBILITY:

Spaced at 1x2 - 12" x 24" Center to Center
Spaced at 1x4 - 12" x 48" Center to Center
Spaced at 2x2 - 24" x 24" Center to Center
Spaced at 2x4 - 24" x 48" Center to Center







SSR Series-Grid Installation Instructions

2225 W Pershing Rd. Chicago, IL 60609 - 773.847.1400 - www.newstarlighting.com

2. Remove LED gear tray.



3. Raise fixture into grid ceiling.
Adjust as necessary to center.






SSR Series-Grid Installation Instructions

2225 W Pershing Rd. Chicago, IL 60609 - 773.847.1400 - www.newstarlighting.com

4. After making necessary electrical connections, reattach LED gear tray.



5. Reattach frame.

